

Welcome and thank you for purchasing your new FragFX PIRANHA from SplitFish Ltd.


The FragFX PIRANHA is specifically designed for the Sony PlayStation 3 and compatible with the most games, however you may find it's best suited to shooting, driving, action and sport games.

To use your FragFX PIRANHA, you are expected to have a working Sony PS 3 console system. The FragFX PIRANHA is a unique patent pending technology developed by SplitFish Ltd.

For more information visit our web site at www.splitfish.com or drop us an email to info@splitfish.com. We will be glad to assist in anyway that we can. Please read the entire manual so that you get the most fun and enjoyment from your new FragFX Controllers.

Happy Fraggling from all the staff at SplitFish Ltd.

BUTTON LAYOUT / INSTALLATION



Plug the FragFX PIRANHA cable into one of the front USB slots on the PS3. The FragFX PIRANHA will be in standby mode with a blue PS button flashing until you press the PS button to link the PS3 with the FragFX PIRANHA. The PS button has 3 color modes depending on which mode you are using the FragFX PIRANHA in. These 3 modes are: Game mode, Mouse mode and Swap mode. There are detailed descriptions in the following sections.



BASIC OPERATION / PS BUTTON LIGHTS

ON: When the blue PS button is slowly flashing press the PS button to turn on your FragFX PIRANHA, this will link the FragFX PIRANHA to the console. A solid blue PS button indicates the FragFX PIRANHA is in Game Mode. The device number assignment can be assigned the same way as any other PS 3 controller. This may be a necessary step if your FragFX PIRANHA does not work.
OFF: Press and hold the PS button and the screen will display a menu that gives you a choice to turn off the FragFX PIRANHA.

PS button Lights:

- **Slow flashing blue:** FragFX PIRANHA is not on. Press the PS button to turn the FragFX PIRANHA on.
- **Solid blue:** FragFX PIRANHA is on and in Game Mode. The FragFX PIRANHA always starts in Game Mode.
- **Solid green:** FragFX PIRANHA is in Mouse Mode (used when you are in the Playstation browser or in the Sony Store).
- **Solid cyan:** FragFX PIRANHA controller is in Swap Mode.



- Blue (Game Mode)
- Green (Mouse Mode)
- Cyan (Swap Mode)

BASIC OPERATION / GAME MODE

In some of the game setup menu you can adjust the button layout of the FragFX PIRANHA same as with a normal PS3 controller. To remap the FragFX PIRANHA button layout, you can download software from our web site - www.splitfish.com. This allows you to further customize the FragFX PIRANHA to your specific game style even if the game doesn't have a controller setup menu.

The FragFX PIRANHA is an intelligent controller that has programming features - please read the next pages to learn about additional FragFX PIRANHA features.

Game Mode (Blue PS Button):

The FragFX PIRANHA has all the normal buttons of a conventional controller as well as additional features.


During game mode the FragFX PIRANHA right hand mouse is used for looking up, down, left and right. Operate R1, R2 and R3 (between R1 + R2) with the fingers that suit you best.

FRAG BUTTON AND SENSITIVITY DIAL

You will find two additional features on the left hand grip. The first feature is the **Frag button** located above the L1 button. During game play you will notice that when the Frag button is pressed the right hand mouse will slow down. This unique feature gives you high accuracy for sniper shots and delicate manoeuvres during game play. The **Frag button** is an analog button and that means that the harder you press it (within its range) the slower the mouse movements will be.

The second unique feature on the left hand grip is the **sensitivity dial** located next to where your left hand thumb rests. The dial allows you to adjust the overall speed of the mouse during game play.

You will quickly realize the value of the combination of the **Frag button** and the **sensitivity dial** during game play. You can adjust the sensitivity dial during game play and that will allow you to use the mouse to look around very quickly. Then by pressing the Frag button you can instantly slow down to aim and shoot. This combination gives you a powerful advantage over normal controllers abilities.



Rapid Fire Procedure:

Rapid fire can be enabled for any button on the right hand gaming mouse (R1, R2, R3, circle, triangle, X or square). To put the FragFX PIRANHA into FPS RAPID FIRE program mode, press at the same time:


FRAG BUTTON

- L3
- R3

Use D-pad Up/Down to increase/decrease firing rate. Once in program mode the blue light will flash and the next button pushed on the gaming mouse will be set in rapid fire mode. To disengage the rapid fire function, press at the same time:

FRAG BUTTON

- L3
- R3



MOUSE MODE / SWAP MODE

Mouse Mode (Green PS Button):

Press and hold the Frag button at the same time as pressing the MOUSE button for one second (you will hear a beep). The PS Button will change to Green indicating the FragFX PIRANHA is in Mouse Mode. This feature allows you to navigate through the Sony Playstation browser, menus, store and PS home environments. To change back to Game mode press the Frag and MOUSE button at the same time.

TIP:

You can adjust the sensitivity dial when in Mouse Mode to have more or less mouse travel.

Swap Mode (Solid Cyan PS Button):

Press and hold the Frag button at the same time as the SWAP button for 1/2 second (you will hear a beep) to change the FragFX PIRANHA to Swap Mode. The PS light will change to solid cyan. The mouse movements and the left stick movement on the controller grips will be swapped. Change back by pressing the Frag and SWAP buttons again. You will hear a beep each time you change the modes.

CARE and MAINTENANCE / SOFTWARE FIRMWARE UPGRADES

Care and Maintenance:

Under the right side mouse is a small red sensor that needs to be clear of obstructions. Small hairs, fuzz, dust or dirt can deflect the light sensor and cause the controller to have erratic behavior. Use a dry cue-tip to carefully clean the lens from obstructions - do not use wet cleaning to clean the optical components.

Software Firmware Upgrades and customized setup.

The FragFX PIRANHA is designed to be a firmware upgradeable device. You can also re-map all the buttons, as well as adjust all the analog button's sensitivity. You will need to download the free firmware upgrade software from our website at www.splitfish.com. This will allow you to upgrade, make or trim your own customized setup for all the buttons and their sensitivities for the best performance according to your game play.

Summary

We hope you have fun and we welcome any comments to info@splitfish.com

WARRANTY and CONDITIONS

There are the usual legal regulations for guarantee and warranty

Hardware:

SplitFish Ltd. („SplitFish“) warrants to the original end user („Customer“) that new SplitFish branded products will be free from defects in workmanship and materials, under normal use, for one year from the original purchase date.

Exclusions:

This warranty excludes (1) physical damage to the surface of the product; (2) replacement or repair of the wires; (3) Water or fluid related damage; (4) damage caused by misuse, neglect, improper installation or testing, unauthorized attempts to open, repair or modify the product; or any other cause beyond the range of the intended use; (5) damage caused by accident, fire, power changes other hazards, or acts of god; or (6) use of the product with any non-fossil device or service if such device or service causes the problem. This warranty is limited to the hardware only.

Replacement:

Products or parts may be new or reconditioned or comparable versions of the defective item. SplitFish warrants any replaced or repaired product, or part for a period of forty-five (45) days from shipment, or through the end of the original warranty, whichever is longer. Customers must provide dated proof of purchase (as stated below) in order to receive warranty protection through the end of the original warranty period.

Obtaining Warranty Service:

Customer must contact SplitFish technical support via www.splitfish.com within the applicable warranty period to obtain warranty or non-warranty service.

WARRANTY and CONDITIONS

Copyright / Disclaimer:

The copyright in all original material contained in this document is held by SplitFish Ltd. and / or by the original creator of the materials. Except as stated below, none of the material may be reproduced, distributed, republished, downloaded, displayed, posted, transmitted, or copied in any form or by any means, without the prior written permission of SplitFish Ltd. and / or the copyrighted owner. Permission is granted to display, copy distribute, and download the material solely for personal, non-commercial use provided that you make no modifications to the material and that all copyright and other proprietary notices contained in the material its retained.

All trademarks, service marks, logos, slogans, domain names, and trade names contained herein are the property of their respective owners. SplitFish disclaims any interest in marks other than it's own.

FCC Part 15 Compliance:

This device complies with part 15 of the FCC rules. Operation is subject to the condition that this device does not cause harmful interference.